

# PC-install

(You must have a WiFi adapter) or a laptop(Windows only)

If you only own a PC or having a hard time setting up with your iOS or Android devices, please do the following.

- 1) Connect the camera for power, and wait until LED light starts to double blink.
- 2) Install: "Search tool": [www.spycameras.com/search-win.exe](http://www.spycameras.com/search-win.exe). Do not run it yet.
- 3) Go to your WiFi setting on your PC and find the camera WiFi (SCS-XXXX..) and connect.  
**PW:0123456789**
- 4) Open and run the "Search Tool" program **OR** simply open up a browser and type in the default IP address: 192.168.88:81 and skip to step (#7)
- 5) Hit next, your camera will be found, hit refresh if needed.
- 6) Double click on the camera listing, a browser will open.
- 7) Input user: admin /pw: admin and sign in as "PC view"\* In order to see the video, you may need to install some Active X, but not necessary for the camera setup.
- 8) Click on settings → network → wireless → search → click on your network → join
- 9) input your WiFi PW at [key]:\_\_\_\_\_ and again on [repeat]:\_\_\_\_\_
- 10) Hit apply and wait one minute. Now the camera will make connection to your router.

If all done correctly, you will not be able to see the camera SSID from step (#3). If you still see the camera SSID from your PC WiFi list, which indicates the camera has failed to connect; most likely due to the WiFi PW error for step (#9). Please repeat the process from step (#3).

---

You now can add the camera to the app.

or

install the PC software, IP camera Client: [www.spycameras.com/lcs.exe](http://www.spycameras.com/lcs.exe) and connect to the cameras. Manual: [www.spycameras.com/lcs.pdf](http://www.spycameras.com/lcs.pdf)